5 Settings			<b>%</b> , 0	@ 2D 1D	(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	2
Connections	1	GS Sensor	2	Point storage	3	
	4	System	5		6	
About Leica Captivate	7					
Fn OK					Fi	'n

From the home screen go to Settings connections all other connections.

$\leftarrow$	<b>Connection Se</b>	ttings	7	×, 0	@	2D 1D	@ [	09:20	
cs	connections GS con	nections					Q		
<b>CS</b> Devi	internet ce CS PXS8 CDMA	Port CS modem							L
<b>GS</b> Devi	rover ce GS14	Port Cable							Г
<b>AS</b> Devi	CII input								S
<b>GS</b> Devi	hidden points ce Disto Sigma	Port Internesto							
<b>Exp</b> Devi	oort job ce -	Port -							
Fn	ОК	Edit					Page	Fn	

## Highlight ASCII input.

## Select Edit



Check the box store ASCII data received via an.

Use the pull down to choose Bluetooth 1, or Bluetooth 2.

Select Device on the bottom of page.



Edit

New

OK

Fn

Delete

Page

Fn

Use the down arrow on the thumb wheel to highlight RS232.

Select New at the bottom of the page.

5 Edit Device		(1) 09:24
Name	sonarmite	
Туре	RS232	
Baud rate	9600	$\checkmark$
Parity	None	$\sim$
Data bits	8	$\vee$
Stop bit	1	$\sim$
Flow control	None	$\vee$
Store		

## Fill in the Name

Change the baud to 4800 The rest of the settings should match the default, if not match the settings in the picture to the left.

Select Store .







